

Testing Documentation History Table

Test Plan	Test Setup	Environmental Parameters	Test Input	Quantifiable Measure Standard	Pass Criteria	Test Results
Test delay between sender and receiver devices	Sender and receiver devices are placed 15 meters apart indoors	Room temperature (20-22 °C), standard atmosphere (101.3kPa)	Press the SW_MEC_5 G button on the sender device	Logged time difference between when the signal is sent (sender) and received (receiver) using timer, signified by red LED turning on	Time difference < 3 seconds	
Test maximum range of communication	Sender and receiver devices are placed 15 meters apart indoors	Room temperature (20-22 °C), standard atmosphere (101.3kPa)	Press the SW_MEC_5 G button on the sender device	Whether the red LED on the receiver device flashes after pressing the button on the sender device	Red LED on receiver device turns on when sender button is pressed	

Test maximum range of communication with wall in between	Sender and receiver devices are placed 5 meters apart indoors, with a wall in between	Room temperature (20-22 °C), standard atmosphere (101.3kPa)	Press the SW_MEC_5 G button on the sender device	Whether the red LED on the receiver device flashes after pressing the button on the sender device	Red LED on receiver device turns on when sender button is pressed
--	---	---	--	---	---

Test red LED flickering rate and duration on caretaker's device	Devices placed 15 meters apart indoors	Room temperature (20-22 °C), standard	Press the SW_MEC_5 G button on the sender device	Red LED flashes for 60 seconds measured by a timer	Red LED flashes for 60 seconds
---	--	---------------------------------------	--	--	--------------------------------

atmosphere
(101.3kPa)

Test feedback
loop timing
from
caretaker's
device to
sender's green
LED

Sender and
receiver devices
are 15 meters
apart indoors

Room
temperature
(20-22 °C),
standard
atmosphere
(101.3kPa)

Press the
SW_MEC_5
G button on
the sender
device

Time difference
between sender's
signal sent and green
LED activation,
recorded on sender
and receiver displays

Green LED
turns on
within 5
seconds of
the sender's
input

Test duration of
green LED on
client's device

Sender and
receiver devices
are 15 meters
apart indoors

Room
temperature
(20-22 °C),
standard
atmosphere
(101.3kPa)

Press the
SW_MEC_5
G button on
the sender
device

Measure how long
green LED shines using
a simple timer (i.e
phone timer)

Green LED
remains
continuously
on for at least
60 seconds

